

• **Over Current Setting Table**

Code No.	Current setting	Actuator Model	Controller Model
A	2.5A	LAS4-1	LAK2; LAK2B; LAK6B; LAKC
B	3.0A	LAS-1; LAS3-1	LAK2; LAKC
C	4.0A	LAS-2; LAS3-2; LAS4-2	LAK2; LAKC
D	5.0A	LAN1-1,-2,-3; LAM3-3,-4	LAK2;LAK2D;LAK4;LAK2B;LAK6B;LAKC
E(24V)	6.0A	LAM3-2; LAN4;	LAK2D; LAK2B; LAKC
E(12V)	6.0A	LAS-1(12V); LAS3-1(12V); LAS4-1(12V)	LAK2(DC); LAKC
F(24V)	7.0A	LAN1-1,-2,-3(24Q); LAM3-1	LAK2D; LAK2B; LAK6B; LAKC
F(12V)	7.0A	LAS-2(12V); LAS3-2(12V)	LAK2(DC); LAKC
G	8.0A	LAM-1,-2,-1A,-2A; LAN2	LAK2; LAK2L; LAKC
H	9.0A	LAN3	LAK6B; LAKC
I	10A	For reservation	
J	12A	For reservation	
K	14A	For reservation	
L	15A	LAN1-1,-2,-3(12V); LAM-1,-2,-1A,-2A(12V)	LAK2(DC) ; LAKC
Z	**A	Special current value (special requirement)	